

# COLORLOCK MATTE

## Professional Grade Paver Sealer

**Matte Finish**

**Ultra Enhancing**

**High Solids**



**Clean and Seal  
in the Same Day!**

**5 Gallons  
MAKES  
10 Gallons!**

### Protect Against:

- **Ultraviolet Fading**
- **Surface Degradation**
- **Mildew Formation**
- **Efflorescence Whitening**

**Colorlock Matte's two-component urethane technology provides all sealable surfaces with the highest level of durability and longevity currently available on the market.**

# COLORLOCK Preparation and Application Guide

---

Colorlock is a clear 2-part sealer designed for concrete pavers and natural stone. Colorlock is a water-based urethane sealer that is nonwhitening and gives a wet look. Colorlock brings back old faded pavers by enhancing the true color.

**SURFACE PREPARATION:** Pavers must be clean and free of any dirt, stains, efflorescence, and failed sealer. The surface can be dry, damp, or moist which allows for cleaning and sealing all in one day. Sanding of pavers before sealing is recommended if joint stabilization is desired.

**MATERIAL PREPARATION:** Mix part A with part B using a paddle mixer or stirring stick for 2 minutes. Part A is 4 parts and part B is 1 part. No measuring is necessary if you are activating a complete kit. Once the two parts are mixed, dilute the sealer 1:1 with plain clean tap water. Only mix what can be used within 2 hours. If you use sealer undiluted, a slippery condition may occur.

**APPLICATION:** Brush, roll, or spray. Apply Colorlock as evenly as possible minimizing puddles and lap marks. Use a 1/2" to 3/4" roller cover for most types of pavers. One coat is recommended for natural stone and dense concrete. Very porous pavers may require a second or third coat. Use a non-skid additive to prevent a slippery condition.

**COVERAGE:** 250— 400 square feet per gallon.

**DRY TIME:** 2 to 4 Hours. Dry times may vary depending on surface porosity, temperature, humidity, and application rate. Light foot traffic in 6 to 8 hours. Vehicular traffic in 48 hours or when the surface is no longer tacky.

**CLEAN UP:** Clean tools with soap and water. Immediately clean spray equipment after use. Run water through the machine until it runs clear. A final rinse of solvent 100 (naptha), TSP solution or laundry detergent will clean any remaining residue.

**LIMITATIONS:** Limitation of Liability: Technical data is true and accurate to the date of issuance but subject to change without notice. Our products conform to our quality standards, but no other warranty is expressed or implied. Liability, if any, is limited to the replacement of the product or purchase price. Labor, cost of labor, or consequential damages is excluded.

## COLORLOCK Same Day Sealing Instructions

1. Inspect the paver deck or driveway for oil spots, stains, weeds, or any unwanted marks.
2. Spray any oil spots, grease spots, or tire marks with Colorback degreaser. Rinse and reapply until the stain is gone.
3. Spray any berry stains, black olive stains, or efflorescence with diluted Colorback stain remover.
4. Pressure clean pavers to remove all remaining dirt, mildew, and foreign residue.
5. A final rinse using the pressure cleaner is recommended. Afterward, sweep or squeegee away any puddles of water.
6. You can now prepare the sealer by mixing part A and part B. Don't forget to dilute 1:1 with water once you have completed your mixing.
7. Apply one coat of Colorlock Paver Sealer by brush, roller or sprayer.

Scan QR Code for Video  
Instructions



Escanee el código QR para obtener  
instrucciones en español

